



ثلاجة

· دلیل المستخدم

الموديل:

RFHA-TM138DS2 A

الرجاء قراءة هذا الدليل بعناية قبل تشغيل الجهاز، واحتفظ به للرجوع إليه فستقبلاً.

هذه التصافيم و الم<mark>واصفات عرضة للتغيير بهدف إدخال</mark> تحسينات عليها و ذلك دون إشعار فسبق.

ISO9001 (B

Refrigerator

User's Manual

Model:

△ RFHA-TM138DS2

Please read this manual carefully before operating your set. Retain it for future reference.

Designs and spec<mark>ifications are subject to change for</mark> improvement without prior notice.

ISO9001 (B







Model: RFHA-TM138DS2

Contents

1. Important Safety Instructions2	3. Location of Controls
2. Grounding Instructions4	4. Operation
2.1 Installation 4	

IMPORTANT SAFETY INSTRUCTIONS

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children aged from 3 to 8 years are allowed to load and unload refrigerating appliances.

Children should be supervised to ensure their do not play with the appliance

For compression-type appliances which use flammable refrigerants, instructions shall include information pertaining to the installation, handing, servicing

Please follow the precautions below for your new refrigerator:

- This refrigerator must be properly installed and located in accordance with the Installation Instructions before it is used.
- 2. Do not allow children to climb, stand or hang on the shelves in the refrigerator. They could damage the refrigerator and seriously injure themselves.
- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.
- Keep fingers out of the clearances between the doors and cabinet. Be careful closing doors when children are in the area.
- 5. Unplug the refrigerator before cleaning and making repairs.
- 6. We strongly recommend that any servicing be performed by a qualified individual.
- Turning the temperature control dial to the "OFF" position stops cooling but does not shut off power to the refrigerator.
- 8. Do not leave refrigerator in extreme cold or warm temperatures.
- 9. Do not place refrigerator near heat sources or open flames.
- 10. Clean the refrigerator with a soft, damp cloth. Remove stains with a mild soap. Do not clean the unit with industrial grade solvents, or abrasive chemicals.
- 11. Do not place heavy items on top of the refrigerator.
- 12. Never install the refrigerator where there is a lot of moisture and water can splash.
- Do not allow children to hang on the doors; the refrigerator may be tipped over and hurt children.
- 14. Never eat spoiled food stored too long in the refrigerator or in an out-of-order refrigerator.
- Do not use sharp tools inside the refrigerator for example to remove ice as damage may occur.
- 16. Unplug and remove food from the refrigerator if not used for a long period of time.
- 17. Caution: flammable refrigerant used! When handing, moving and use of the refrigerator,make sure to avoid either damaging the refrigerant tubing, or increasing the risk of a leak.
- 18. The refrigerant isobutene (R600a) is contained within the refrigerant circuit of the appliance, a natural gas with a high level of environmental compatibility, which is nevertheless flammable. During transportation and installation of the appliance, ensure that none of the components of the refrigerant circuit becomes damaged. The refrigerant (R600a) is flammable.
- 19. WARNING: Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction,
- 20. WARNING: Do not damage the refrigerant circuit.
- 21. WARNING: Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.

IMPORTANT SAFETY INSTRUCTIONS

- 22. WARNING: Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
- 23. WARNING:Food needs to be packes in bags before putting into the refrigerator, and liquids need to be packes in bottles or capped containers to avoid the problem that the product design structure is not easy to clean.
 - The symbol is a warning and indicates the refrigerant and insulation blowing gas are flammable.
- 24. WARNING: Risk of fire /flammable materials

PROPER DISPOSAL

This product should not be disposed with other household wastes. To prevent possible harm to the environment or human health from uncontrolled waste disposal recycles it responsibly to promote the sustainable reuse of material resources. To return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling

WARNING! Refrigerators contain refrigerant and gases in the insulation. Refrigerant and gases must be disposed of professionally as they may cause eye injuries or ignition Ensure that tubing of the refrigerant circuit is not damage prior to proper disposal.

An empty refrigerator is an extremely dangerous attraction to children. If you are getting rid of your old refrigerator, please follow the instructions in the Child Entrapment Warning.

CHILD ENTRAPMENT WARNING:

Risk of child entrapment. Before you throw away your old refrigerator or freezer:

- Take off the doors.
- 2. Leave the shelves in place so that children may not easily climb inside.

CAUTION: USE OF AN EXTENSION CORD IS NOT RECOMMENDED.

FOR HOUSEHOLD USE ONLY SAVE THESE INSTRUCTIONS

GROUNDING INSTRUCTIONS

This appliance must be grounded. In the event of an electrical short circuit, grounding reduces the risk of electric shock by providing an escape wire for the electric current. This appliance is equipped with a cord having a grounding wire with a grounding plug. The plug must be inserted into an outlet that is properly installed and grounded.

WARNING: Improper use of the grounding plug can result in a risk of electric shock. Consult a qualified electrician or service person if the grounding instructions are not completely understood, or if doubt exists as to whether the appliance is properly grounded.

If it is necessary to use an extension cord, use only a three wire extension cord that has a three blade grounding plug, and a three slot receptacle that will accept the plug on the appliance. The marked rating of the extension cord should be equal to or greater than the electrical rating of the appliance.

INSTALLATION

1. Steady, flat location:

If the refrigerator is not leveled during installation, the doors may not close or seal properly, causing cooling, frost, or moisture problems. It is very important for the refrigerator to be level in order to function properly.

To level your refrigerator, you may either turn the level leg clockwise to raise that side to the refrigerator or turn counter-clockwise to lower that side. Having someone push against the top of the refrigerator will take some weight off the leveling leg. This makes it easier to adjust the leveling leg.

Ventilation: Place refrigerator approximately 5 inches from the wall to ensure proper airflow to the compressor. Do not place refrigerator near any heat resources such as a heater or stove as it will put a strain on the compressor.

Power supply:


- Check your local power source. This refrigerator requires a 220V240-V,50Hz power supply.
- Use a receptacle that will accept the ground prong. The power cord of this appliance is equipped with a 3-prong (grounding) plug which mates with a standard 3-prong (grounding) wall outlet to minimize the possibility of electric shock hazard from this appliance. Do not use extension cords or ungrounded(two prong) adapters.

NOTES:


The refrigerator should always be plugged into its own individual electrical outlet which has a voltage rating that matches the rating plate.

If you have only a standard 2-prong wall outlet, it is your personal responsibility and obligation to have it replaced with a properly grounded 3-prong wall outlet.

Never unplug your refrigerator by pulling on the power cord. Always grip plug firmly and pull straight out from the outlet.




© Alhafidh Group Trading fzco, 2019



LOCATION CONTROLS

DOOR CLOSED




www.alhafidh.com

- 1. Freezer Door
- 2. The Handle
- 3. Refrigerator Door
- 4. Leveling Feet

LOCATION OF CONTROLS (CONTINUED)

DOOR OPEN




- 1. Freezer Compartment
- 2. Light Bulb (Behind Thermostat)
- 3. Thermostat Control Knob
- 4. Shelf
- 5. Refrigerator Compartment

© Alhafidh Group Trading fzco. 2019 Reproduction in whole or in part is strictly prohibited

- 6. Crisper Drawer
- 7. Bottle Storage
- 8. Can rack 9. Door Gasket

OPERATION

USING THE THERMOSTAT



The thermostat control knob for the refrigerator and freezer is located at the upper right hand corner of the refrigerator compartment.


The first time you turn the unit on, adjust the thermostat control knob to "4" and give your refrigerator time to cool down completely before adding food; a full 24 hours is recommended.

After it is fully cooled, test it and adjust towards "1" to make less cool or towards "7" to cool more to best suit your needs. However, the setting of "4" should be appropriate for home or office refrigerator use.

NOTE: Turning the control knob to the "OFF" position will stop the cooling cycle.

DEFROSTING

7



Refrigerator compartment: Defrosting process is automatic; melted frost flows into drip tray and automatically evaporates.


Freezer compartment: Defrosting for the freezer must be performed manually.

- 1. Turn the thermostat knob to the "OFF" position and leave the freezer door open.
- 2. Remove all food and ice cube tray or transfer to refrigerator compartment.
- Place towel under compact refrigerator or move refrigerator outdoors where no water damage can occur.
- 4. Clean and wipe out the melted frost with a cloth.

NOTE: To avoid damaging the freezer compartment wall, do not use any sharp objects to remove the frost or to separate the frozen food.

OPERATION (CONTINUED)


REPLACING THE LIGHT BULB



- Unplug refrigerator or disconnect refrigerator from power supply before you remove the light hulb
- Unscrew the middle parts of the thermostat holder assembly, marked by the arrows in the diagram.
- 3. Pull the light bulb cover (thermostat holder assembly) outward to remove it.
- 4. Unscrew the light bulb.
- Replace with a 15-watt 220V appliance bulb only. (Not all bulbs will fit your refrigerator. Be sure to replace the bulb with the same screw Type E14- and shape. The T6 can be used.)
- Plug in refrigerator or reconnect refrigerator to power supply.

OPERATION

USING THE THERMOSTAT



The thermostat control knob for the refrigerator and freezer is located at the upper right hand corner of the refrigerator compartment.


The first time you turn the unit on, adjust the thermostat control knob to "4" and give your refrigerator time to cool down completely before adding food; a full 24 hours is recommended.

After it is fully cooled, test it and adjust towards "1" to make less cool or towards "7" to cool more to best suit your needs. However, the setting of "4" should be appropriate for home or office refrigerator use.

NOTE: Turning the control knob to the "OFF" position will stop the cooling cycle.

DEFROSTING

7



Refrigerator compartment: Defrosting process is automatic; melted frost flows into drip tray and automatically evaporates.


Freezer compartment: Defrosting for the freezer must be performed manually.

- 1. Turn the thermostat knob to the "OFF" position and leave the freezer door open.
- 2. Remove all food and ice cube tray or transfer to refrigerator compartment.
- Place towel under compact refrigerator or move refrigerator outdoors where no water damage can occur.
- 4. Clean and wipe out the melted frost with a cloth.

NOTE: To avoid damaging the freezer compartment wall, do not use any sharp objects to remove the frost or to separate the frozen food.

OPERATION (CONTINUED)

REPLACING THE LIGHT BULB



- Unplug refrigerator or disconnect refrigerator from power supply before you remove the light hulb
- Unscrew the middle parts of the thermostat holder assembly, marked by the arrows in the diagram.
- 3. Pull the light bulb cover (thermostat holder assembly) outward to remove it.
- 4. Unscrew the light bulb.
- Replace with a 15-watt 220V appliance bulb only. (Not all bulbs will fit your refrigerator. Be sure to replace the bulb with the same screw Type E14- and shape. The T6 can be used.)
- Plug in refrigerator or reconnect refrigerator to power supply.

OPERATION (CONTINUED)

Changing the door from the right side to the left.

The side at which the door opens can be changed from the right side (as supplied) to the left side, if the installation site requires. Tools you will need:

8mm socket driver



■ phillips screwdrivers



■ Putty Knife or slotted srewdrivers



7mm wrench



Parts you will need ,parts are from the package of manual






door stopper

Caution:

-To avoid to injury yourself and/or property, we recommend someone assist you during the door reversal process.


- -Ensure the Appliance is unplugged and empty.
 -Following steps are generally recommended.
- 1. Stand the refrigerator, open the upper door and remove the things in the door and
- 2, open the screw hole cove and the upper hinge cover which is at the top right corner of the refrigerator



3.Unscrew the special flange self-tapping screws which are used for fixing the right upper hinge part by a 8mm socket driver or a spanner (please support the upper door with your hand when doing it).



4.Remove the right upper hinge part and screw hole cover place them on the smooth surface



5.Remove upper door and place it on smooth surface with panel upwards.


6. Loose screws used to fix middle hinge and remove middle hinge. Then turn middle hinge by 180. Take washer on axis and put it on another end. Place it well for use.




7. Remove lower door and place panel upwards on smooth surface.

8. Change screw hole covers on middle cover plate from left to right (as shown in figure below).






9. Use the 8mm socket driver to remove lower hinge part and front foot hinge part and front foot fixed board. Then Screw Note: washer may stick to lower door. out lower hinge axis



Note: Before this step, you should lay the refrigerator on it's back in order to gain access to the base, you should rest it on soft foam packaging or similar material to avoid damaging the cooling pipes at the rear of the refrigerator.

OPERATION CONTINUED

10. Change lower hinge part to left and front foot fixed board to right and fix them with screws. Then install adjustable bottom feet parts.




11.Remove the door stop (right) and door stopper (right) with Phillips screwdrivers Install the door stopper (left) and door stop (left) which are from the package of user's manual



- 1) Door stop (left)-from package of manual
- (2) Door stopper (left)-from package of manual
- (3) Self-tapping screws
- (4) Door stop (right)
- (5) Door stopper (right)

© Alhafidh Group Trading fzco. 2019

Stand the refrigerator then move lower door and adjust its position to align lower hole(left) site and lower hinge axis. Then adjust middle hinge and align the middle hinge axis to the higher (left) hole site. Then install the middle hinge.



12. Screw out top hinge axis, and change it to the near hole site. then screw up .Move upper door to appropriate position,



13. Replace and Install the right upper hinge cover on the left corner, Replace the screw hole cover on the right corner.



14. Stand and level the appliance.

Before the appliance is powered, We recommend that you should wait for about To avoid contamination of food, please respect the following instructions

- Opening the door for long periods can cause a significant increase of the temperature in the compartments of the appliance.
- Clean regularly surfaces that can come in contact with food and accessible drainage systems.
- Store raw meat and fish in suitable containers in the refrigerator, so that it is not in contact with or drip onto other food.
- Two-star frozen-food compartments are suitable for storing pre-frozen food, storing or making icecream and making ice cubes.
- One-, two- and three-star compartments are not suitable for the freezing of fresh food.

Order	Compartments TYPE	Target storage temp.[℃]	Appropriate food
1	Fridge	+2~+8	Eggs, cooked food, packaged food, fruits and vegetables, dairy products, cakes, drinks and other foods are not suitable for freezing.
2	(***)*-Freezer	≤-18	Seafood (fish, shrimp, shellfish), freshwater aquatic products and meat products (recommended for 3 months, the longer the storage time, the worse the taste and nutrition), suitable for frozen fresh food.
3	***-Freezer	≤-18	Seafood (fish, shrimp, shellfish), freshwater aquatic products and meat products (recommended for 3 months, the longer the storage time, the worse the taste and nutrition), are not suitable for frozen fresh food.
4	**-Freezer	≤-12	Seafood (fish, shrimp, shellfish), freshwater aquatic products and meat products (recommended for 2 months, the longer the storage time, the worse the taste and nutrition), are not suitable for frozen fresh food.
5	*-Freezer	≪-6	Seafood (fish, shrimp, shellfish), freshwater aquatic products and meat products (recommended for 1 months, the longer the storage time, the worse the taste and nutrition), are not suitable for frozen fresh food.
6	0-star	-6~0	Fresh pork, beef, fish, chicken, some packaged processed foods, etc. (Recommended to eat within the same day, preferably no more than 3 days). Partially encapsulated processed foods (non-freezable foods)
7	Chill	-2~+3	Fresh/frozen pork, beef, chicken, freshwater aquatic products, etc.(7 days below 0 °C and above 0 °C is recommended for consumption within that day, preferably no more than 2 days). Seafood (less than 0 for 15 days, it is not recommended to store above 0 °C)

www.alhafidh.com

8	Fresh Food	0~+4	Fresh pork, beef, fish, chicken, cooked food, etc. (Recommended to eat within the same day, preferably no more than 3 days)
9	Wine	+5~+20	red wine,white wine,sparkling wine etc.

Note: please store different foods according to the compartments or target storage temperature of your purchased products.

- If the refrigerating appliance is left empty for long periods, switch off, defrost, clean, dry, and leave the door open to prevent mould developing within the appliance.

 Water dispenser cleaning (special for water dispenser products):
- Clean water tanks if they have not been used for 48 h; flush the water system connected to a water supply if water has not been drawn for 5 days.

© Alhafidh Group Trading fzco. 2019

يرجى اتباع التعليمات التالية لتجنب تلوث الطعام.

- ــــر، كى خامك النبية من المنطقة عند المنطقة عند المنطقة عند المنطقة المنطقة المنطقة المنطقة المنطقة المنطقة ا يظف بانتظام الاسطح التي يمكن أن تتلامس مع الطعام، وأنظمة الصرف التي يمكن الوصول اليها. خزَّن اللحوم، النيئة والأسماك في حاويات مناسبة في الثلاجة، بحيث لا تتلامس مع الأغذية الأخرى أو تقطر فوقها. تكون حجرات الطعام، المجمد ذات النجمتين مناسبة لتخزين الأطعمة المجمدة مسبقاً أو تخزين الآيس كريم، أو صنعها وصنع
 - مكعبات الثلُج.
 - لا تعد حجرات النجمة الـواحدة والنجمتين والثلاث نجوم مناسبة لتجميد الطعام الطازج.

الطعام المناسب	درجة حرارة التخزين المستهدفة (درجة مئوية)	الأنوع الحجرةمر	الأمر
البيض، والأطعمة المطبوخة، والأغذية المعلبة، والفواكه والخضروات، ومنتجات الألبان، والكيك، والمشروبات وغيرها من الأطعمة غير مناسبة للتجميد.	8+~2+	الثلاجة	1
المأكولات البحرية (السمك، الجمبري، المحار)، والمنتجات المائية ومنتجات اللحوم, (يوصي بتخزينها لمدة ٣ أشهر، وكلما طالت فترة التخزين زاد سوء الطعم, والتغذية) مناسبة للأغذية الطازجة المجمدة.	18-≤	(***)–المجمدة	2
المأكولات البحرية (السمك، الجمبري، المحار)، والمنتجات المائية ومنتجات اللحوم, (يوصي بتخزينها لمدة ۳ أشهر، وكلما طالت فترة التخزين زاد سوء الطعم, والتغذية) غير مناسبة للأغذية الطازجة المجمدة.	18-≪	***–المجمدة	3
المأكولات البحرية (السمك، الجمبري، المحار)، والمنتجات المائية ومنتجات اللحوم, (يوصي بتخزينها لمدة شهرين، وكلما طالت فترة التخزين زاد سوء الطعم, والتغذية) غير مناسبة للأغذية الطازجة المجمدة.	12-≤	**–الەخەدە	4
المأكولات البحرية (السمك، الجمبري، المحار)، والمنتجات المائية ومنتجات اللحوم, (يوصي بتخزينها لمدة شهر، وكلما طالت فترة التخزين زاد سوء الطعم والتغذية) غير مناسبة للأغذية الطازجة المجمدة.	6-≤	*–المجمدة	5
لحم البقر، والسمك، والدجاج، وبعض الأطعمة المجهزة المعلبة وما إلى ذلك. (يوصى بتناولها في نفس اليوم، ويفضل ألا يزيد تخزينها عن 3 أيام). الأطعمة المجهزة المغلفة جزئياً (الأطعمة غير القابلة للتجميد).	0~6-	0 نجمة	6
لحم البقر، والدجاج، والمنتجات المائية وما إلى ذلك (يوصي بتخزينها ۷ أيام, مع ضبط درجة الحرارة أقل من ، درجة مثوية أو أعلى من ، درجة مثوية للاستهلاك خلال ذلك اليوم, ويفضل ألا يزيد ذلك عن يومين). الماكولات البحرية (يوصي بتخزينها من ، إلى ما يوماً، ولا ينصح بتخزينها في درجة حرارة أعلى من ، درجة مثوية).	3+~2-	تبريد	7

لحم البقر، والسمك، والدجاج، والطعام, المطبوخ وما إلى ذلك (يوصى بتناوله في نفس اليوم، ويفضل ألا يزيد تخزينه عن ٣ أيام).	+4~0	الطعام الطازج	8
النبيذ الأحمر والنبيذ الاأيض والنبيذ الفوار، وما إلى ذلك.	+20~+5	النبيذ	9

ملاحظة: يرجى تخزين الأطعمة المختلفة وفقاً للحجرات أو درجة حرارة التخزين المستهدفة للمنتجات التي اشتريتها.

تنظيف براد الماء (خاص للمنتجات التي تحتوي على براد ماء المياه):

– نظُّف خزانات المياه إذا لم, تستخدم لمدة ٨٨ ساعة؛ جدد نظام المياه المتصل بإمدادات المياه إذا لم, تُسحب المياه لمدة ٥ أيام.

© Alhafidh Group Trading fzco. 2019 Reproduction in whole or in part is strictly pro

[–] في حال رغبت بترك الثلاجة فارغة لفترات طويلة، قم بإيقاف التشغيل وإذابة الثلج والتنظيف والتجفيف واترك الباب مفتوحاً لمنع تكون العَفْن داخل الجهاز.

لتشغيل (تابع)

تغيير موضع الباب من الجانب الأيمن إلى الجانب الأيسر.

يمكن عكس الجانب الذي يفتح منه الباب من الجانب الأيمن .. (كما هو عند الشراء) إلى الحانث الأنسر، إذا كان مكان التركيب يتطلب ذلك. الأدوات التي ستحتاجها:

> • مفك صواميل مقاس 8 ملم • مفك فىلىيس

• سكين فعجون أو ففك يراغي فشقوق



الأجزاء التي ستحتاجها من مجموعة الدليل




حاحز الباب

سدادة باب

لتحنب إصابة نفسك و/ أو إلحاق الضرر بالممتلكات، نوصي بوحود شُخص ما لمساعدتُكُ أثناَّء عمليَّةٌ عكس البات. * تأكد من أن الثلاحة فارغة ومفصولة عن مصدر التبار الكهربائي.

* ينصّح بأتّباع الخطوات التالية بشكل عام.

 اجعل الثلاجة في وضع رأسي وافتح الباب العلوي وأزل <mark>الأشياء الم</mark>وجود في الباب وأغُلقه." 2. افتّح غطاُء فُتحة البراغي وغطاء المفصلة العلوبة الموجود <mark>فى الركن الأيم</mark>ن العلوى من الثلاحة.



 فك البراغي الملولية الخاصة ذاتية الحفر والمستخدمة لتثبيت المفصّلة العلوية في الركن الأيمن باستخدام مفك صو<mark>امیل مقاس 8 ملم أو باستخدام</mark> مفتاح ربط (پُرجی إمساك البائب العلوي بيدك بإحكام أثناء فك البراغُيّ منعاً لانزلاقه).



4. أزل المفصلة العل<mark>وية في الركن الأيمن وغطاء.</mark> فتحة البراغو ، وضعهم ع<mark>لى أسطح أفلس.</mark>




5. أزل الباب العلوى وضعه على سطح أفلس فع وضع اللوحة لأعلى.

6. فك البراغي المستخدمة لتثبيت المفصلة الوسطى وأزل المفصلة الوسطى. ثُمَّ أدر المفصلة الوسطى بمقدار 180 درجة. افسك الحلقة المُوحودة على المُحور وضعها في طرف آخر. ضعها حبداً للاُستخداه لاحقاً. ُ



7. أزل الباب السفلى وضع اللوحة لأعلى على سطح





9. استخدم مفك صواميل

مقاس 8 ملم لازالة المفصلة السفلية ولوحة القدم الأمامية الثابتة. ثم فك محور المفصلة السفلىة وغيره إلى مكان الفتحةُ القريبة، ثُم شد البراغى وثبت الحلقة.

ملاحظة: قبل تنفيذ هذه الخطوة، يجب وضع الثلاجة على جانبها الخلفي لكي تتمكن من الوصول إلى القاعدة ووتضعها على مواد التَّغليفُ اللِّينَةِ المصنوعةُ من الإسفنج أو أي مواد مماثلة لتحنب تعرض أناسب التبريد الموجودة في الجانب الخلفي للتلف.

التشغيل (تابع)

10. قم يتغيير موضع المفصلة السفلية نحو اليسار ولوحة القدم الأمامية الثابتة نحو اليمين واربطها بالبراغي. ثم ركُّب القدم السفلية القابلة للتُعديلُ.



11. أزل حاجز الباب (الركن الأيمن) وسدادة الباب (الركن الأيمن) باستخدام ففك فيليبس، رَكُب سدادة الباب (الركنَ الأنسر) وحاجز الباب (الركن الأنسر) من مجموعة دليل



(1) حاجز الباب (الركن الأيسر) - من مجموعة الدليل


(2) سدادة الياب (الركن الأيسر) - من مجموعة الدليل

(3) البراغي الملولية الخاصة الذاتية الحفر


(4) حاجز الباب (الركن الأيمن)

(5) سدادة الباب (الركن الأبمن)

اجعل الثلاجة في الوضع الرأسي ثم حرَّك الباب السفلي واضبط موضعه لَّمحاذاة مكان الفَّتحة السفلية (يسار) ومحوَّر المفصلة السفلية. ثم اضبط المفصلة الوسطى وقم بمحاذاة محور المفصلة الوسطى مع مكان الفتحة العلبا . (البسار). ثم ركّب المفصلة الوسطى.



12. فك براغي محور المفصلة العلوية وغيره إلى مكان الفتحة القريبة، ثم شد البراغي. حرك الباب العلوي إلى الموضع المناسب.



13. استبدل وركب غطاء المفصلة العلوية الأيمن في الركن الأيسر، واستبدل غطاء فتحة البراغي في الركنّ



10


14. ضع الجهاز في الـوضع الرأسي واحرص <mark>علي أن يكـون</mark>

ملاحظة:

قبل تشغيل الجهاز، نوصيك بالانتظار <mark>لمدة ساعتين تقريباً.</mark>

التشغيل

استخدام الثرموستات




يقع مقبض التحكم في ثرموستات الثلاجة والمجمدة في الجزء العلوي الأيمن من حجرة التبريد.

في المرة الأولى التي تقوم, فيها بتشغيل الوحدة، اضبط مقبض التحكم, في الثرموستات على "4" واترك الثلاجة فترة لتبرد تماماً قبل إدخال الصعام؛ يُنصح بفترة 24 ساعة كاملة.

بعد أن يتم تبريد الثلاجة بالكامل، اختبرها واضبطها على "1" لجعلها أقل برودة أو على "7" لتبرد بشكل أعلى لتناسب احتياجاتك بشكل أفضل. ومع ذلك، يكون الإعداد "4" مناسباً لاستخدام الثلاجة في المنزل أه المكتب.

ملاحظة: يؤدي دوران مقبض التحكم نحو وضع الإغلاق OFF إلى إيقاف دورة التبريد.

إذابة الثلج



حجرة التبريد: تُعد عملية إذابة الثلج تلقائية، حيث يتدفق الثلج الذائب إلى درج التنقيط وبخر تلقائياً.

حجرة التجميد: يجب إذابة الثلج في الثلاجة يدوياً.

ا. أدر مقبض الثرموستات نحو وضع الإغلاق OFF واترك باب المجمدة مفتوحاً.


 آزل جميع الأطعمة وصينية مكعبات الثلج أو انقلها إلى حجرة التبريد.

٣. ضع منشّفة تُحت الثّلاجة أو حرك الثلاجة إلى الخارج بحيث لا يحدث أي ضرر من المياه. ٤. نظّف وامسح الثلج الذائب باستخدام, قطعة قماش .

ملاحظة؛ لتجنب تلف جدار حجرة التجميد، لا تستخدم أي أدوات حادة لإزالة الثلج أو لفصل الطعام المحمد.

التشغيل (تابع)


استبدال مصباح الإضاءة



- انزع قابس الثلاجة أو افصل الثلاجة عن مصدر الطاقة الكهربائية قبل إزالة مصباح الإضاءة.
- 2. فك الأجزاء الوسطى من مجموعة حامل الثرموستات المميزة بأسهم في المخطط.
- اسحب غطاء مصباح الإضاَّءة (مجموعة حامل الثرموستات) إلى الخارج لإزالته.
 - 4. فك مصباح الإضاءة.
- أستبدله بمصباح ۱۰ وات 220 فولت فقط.
 (لا تلائم جميع المصابيح ثلاجتك. تأكد من استبدال المصباح بنفس نوع البرغي E-14 وشكله. يمكن استخدام برغي من نوع T6.
- وسطة. يملطن الشخصام برغاي هن فوج ١٥). 6. وصِّل قابس الثلاجة أو أعد توصيل الثلاجة بمصدر الطاقة الكهربائية.

أماكن مكونات الثلاجة

الباب مغلق




1. باب المجمدة 2. المقبض 3. باب الثلاجة 4. أقدام التسوية

5

أماكن مكونات الثلاجة (تابع)

الباب مفتوح



- 1. حجرة التجميد 2. مصباح إضاءة (خلف الثرم<mark>وستات)</mark>
- 2. مطباح إطاءه رحله الترموستات 3. مقبض التحكم في ال<mark>ثرموستات</mark>
- د. مقتبط التخصير في البرموسيات 4. رف
 - ٠. رك 5. حجرة التبريد
 - . 6. درج اُلخضراوات وا<mark>لفواكه</mark>
 - 7. أَمُاكَن تَحَزُيُن الزُ<mark>جَاجَات</mark>
 - 8. رفوف العلب
 - 9. حُشَية الباب

تعليمات مهمة للسلامة

22. تحذير: يجب تعبئة الطعام, في أكياس قبل وضعه في الثلاجة, ويجب تعبئة السوائل في زجاجات أو في أوعية مغطاة لتجنب التعرض لمشكلة صعوبة التنظيف بسبب تصميم الجهاز.

الرمز 🛕 هـو تحذير يشير إلى أن سائل التبريد وغازات النفخ العازلة مواد قابلة للاشتعال.

24. تحذير: خطر اندلاع حريق/ مواد قابلة للاشتعال.

التخلص من الجهاز على النحو الصحيح

يحب عدم التخلص فن هذا المنتج فع المخلفات المنزلية العادية.

لـّتَفادي المخاطر المحتَملة على البيئة أو صحة البشر من أثر الاتخلص غير الصحيح من النفايات، يُرجى التخلص من النفايات بشكل مسؤول لتعزيز إعادة الاستخدام المستدام للموارد. لإرجاع جهازك المستعمل، يُرجى اتباع أنظمة الإرجاع والتجميع أو الاتصال بالبائع الذي اشتريت منه المنتج، إذ إن بإمكانهم إعادة تدوير هذا المنتج بطريقة آمنة بيئياً.

تحذير! تحتوى الثلاجات على سائل تبريد وغازات في المواد العازلة.

يجبُ التخلصُّ من سائل التَّبريد والْغازات بطريقة أحترافية لأنها قد تسبب إصابات العين أو الاشتعال. تأكد من عدم تلف أناسب دائرة التبريد قبل التخلص منها بشكل سليم.

تمثل الثلاجة الفارغة عامل جذب بالغ الخطورة للأطفال. إذا رغبت بالتخلص من ثلاجتك القديمة، يرجى اتباع التعليمات الموضحة في التحذيرات الخاصة بالأطفال.

التحذيرات الخاصة بالأطفال:

خطر انحباس الطفل. قبل التخلص من الثلاجة أو المجمدة القديمة، عليك القيام بما يلي: 1. اخلع الأيواب.

اترك الرفوف في مكانها حتى لا يصعد الأطفال إلى الداخل بسهولة.

<mark>تنبیه</mark>: یوصی بعدم استخدام سلك توصیل.

للاستخدام المنزلي فقط احتفظ بهذه التعليمات

تعليمات التأريض

يجب أن يرتكز هذا الجهاز على الأرض. في حال حدوث ماس كهربائي، يقلل التأريض من خطورة التعرض لصعق كهربائي عن طريق توفير سلك إضافي يسمح بمرور التيار الكهربائي. هذا الجهاز مزود بكابل له سلك تأريض ومعه قابس تأريض. يجب توصيل القابس بمنفذ تيار فَرَكب وفُؤرَض بشكل سليم.

> <mark>تحذير</mark>: يمكن أن يؤدي الاستخدام, غير الصحيح لقابس التاريض إلى خطر التعرض لصعق كمربائي. استشر فني الكمرباء أو فني الصيانة المختص إذا كانت تعليمات التاريض غير مفهومة بالكامل أو إذا كان لديك شك ما بشأن التاريض السليم, للجهاز من عدمه

> عدى. وتقابل من الضروري استخدام كابل توصيل استخدم فقط كابل توصيل ثلاثي الأسلاك يحتوي على قابس تاريض ثلاثي الشفرات ومقبس ثلاثي الفتحات بحيث يستوعب قابس الجهاز. يجب أن يكون التصنيف المحدد لكابل التوصيل مساوياً للتصنيف الكمربائي للجماز أو أعلى منه.

لتركيب

1. مكان ثابت ومسطح:

إذا لم, تكن الثلاجة مستوية أثناء التركيب، قد لا تُغلق الأبواب أو تُقفل بشكل صحيح، مما يسبب مشكلات في التبريد أو التجميد أو مشكلات متعلقة بالرطوبة. من المهم جداً أن تكون الثلاجة مستوية حتى تعمل بشكل صحيح. لتسوية الثلاجة، يمكنك إما تدوير قدم التسوية في اتجاه عقارب الساعة لرفع هذا الجانب من الثلاجة أو تدويره عكس اتجاه عقارب الساعة لخفض ذلك الجانب. سيؤدي دفع شخص ما للجزء العلوي من الثلاجة إلى التخفيف من ثقل قدم التسوية، مما يسهل ضبطها.

 التهوية: ضع الثلاجة على بعد حوالي ٥ بوصة من الحائط لضمان تدفق الهواء بشكل صحيح إلى الضاغط. لا تضع الثلاجة بالقرب من أي موارد حرارية مثل السخان أو الطباخ، لأن ذلك يولد جهداً على الضاغط.

3. مصدر الطاقة الكّهربائية:

- افحص مصدر الطاقة المحلى. تتطلب هذه الثلاجة مصدر طاقة كهربائية بقوة 240-220 فولت و٥٠ هرتز.
- استخدم مقبساً يتوافق مع النَّشق المتصل بالأرضّ. تم تزويد سلك الطاقة في هذا الجهاز بقابس (تأريض) ثلاثي ال<mark>شقوق</mark> والذي يتوافق مع منفذ الحائط القياسي ثلاثي الشقوق (الأرضي) لتقليل احتمال التعرض للصعق الكهربائي بواس<mark>طة هذا</mark> الحهاز. لا تستخدم أسلاك التوصيل أو المهابئات المفردة غير المؤرضة (ثنائية الشقوق).

ملاحظات:

يجب توصيل الثلاجة دائماً بمنفذ تيار كهربائي فردي خاص بها له جهد مقنن يطابق لوحة التصنيف. إذا كان لديك منفذ حائط قياسي ثنائي الشقوق فقط، فعليك الالتزام باستبداله بمنفذ حائط ثلاثي <mark>الشقوق مؤرض</mark> بشكل صحيح.

لا تفصّل التيّار الكهربائي عن الثلاجة عن طريق سحب سلك الكهرباء مطلقاً. احرص دائماً على إم<mark>ساك القابس بإحكام.</mark> واسحبه بشكل مستقيم من منفذ الكهرباء.





الطراز: RFHA-TM138DS2

© Alhafidh Group Trading fzco. 2019

المحتوبات

1. تعليمات مهمة للسلامة	
1. تعلیمات التأریض1	
2.1 التركيب2	

تعليمات مهمة للسلامة

هذا الجهاز غير مصمم للاستخدام، من قبل الأشخاص (بما في ذلك الأطفال) ذوي القدرات البدنية أو الحسبة أو الذهنبة الضعيفة أو ذوى الخيرة والمعرفة القليلة، ما لم يتلقوا الإشرافُ أو التعليمات المتعلَّقة باستخدام الحهاز بواسطة شخص مسؤول عن سلّامتهم.

4. التشغيل ..

3. أماكن مكونات الثلاحة......

يمكن للأطفال الذين تتراوم أعمارهم من 3 إلى 8 سنوات تعبئة الثلاجات وتفريغها. يجب مراقبة الأطفال لضمان عدم عيثهم بالحهاز. بالنسبة للأحهزة التي تعمل بالضغط والتي تستخدم سوائل تبريد قابلة للاشتعال، بحب أن تتضمن التعليمات معلومات تتعلق بالتركيب والمناولة والصيانة.

يرجى اتباع الاحتياطات التالية عند استخدام ثلاجتك الجديدة:

1. يجب تركيب هذه الثلاجة وتعيين مكانها بشكل صحيح وفقاً لتعليمات التركيب قبل الاستخدام.

2. لا تسمح للأطفال يتسلق رفوف الثلاجة أو الوقوف عليها أو التشبث بها، حيث قد يؤدى ذلك إلى تلف الثلاجة وتعرضهم

3. يُحظر تخزين أو استخدام البنزين أو الأبخرة والسوائل الأخرى القابلة للاشتعال بالقرب من هذا الجهاز أو أي جهاز آخر.

4. انعد أصابعك عن المسافة الفاصلة بين الأيواب والخزانة. كن جذراً عند إغلاق الأيواب أثناء وجود أطفال أفي المكان.

5. انزع قايس الثلاجة قبل التنظيف أو الصيانة.

نوصى بشدة بإجراء الصيانة من قبل فنى مؤهل لذلك.

7. يؤدي توران قرص التحكم في درجة الحرارة نحو وضع الإغلاق OFF إلى توقف التبريد ولكنه لا يؤدي إلى إيقاف ت<mark>شغيل</mark>

8. لا تترك الثلاحة في درحات الحرارة شديدة البرودة أو السخونة.

9. لا تضع الثلاحة بالتَّقرب من مصادر الحرارة أو اللهب المكشوف.

10. نظف الثلاحة باستخدام قطعة قماش ناعمة ومبللة. أزل البقع باستخدام سائل تنظيف مخفف. بُحظر <mark>تنظيف الوحدة</mark> . باستخدام مذبيات صناعية أو قواد كيميائية كاشطة.

11. لا تضع أغراض ثقيلة فوق الثلاحة.

12. يُحظر تركيب الثلاجة في مكان ذو رطوية عالية وتتناثر عليه قطرات الماء.

13. لا تسمح للأطفال بالتشَّيث على الأيواب؛ قد تنقلب الثلاجة وتلحق الأذي بالأطفال.

14. يُحضر تناول الطعام الفاسد الذي تم تخزينه في الثلاجة لفترة طويلة جِداً أو الموجود في أي ث<mark>لاجة معطلة.</mark>

15. لا تستخدم الأدوات الحادة داخل الثلاجة –على شبيل المثال لإزالة الجليد – قد يؤدي ذلك إل<mark>ى حدوث أضرار.</mark>

16. انزع قابس الثلاجة واخرج الطعام منها إذا لم تُستخدم لفترة طويلة من الزمن.

17. تنبيه؛ هناك سوائل تبريد قابلة للاشتعال! عند تحريك الثلاجة ونقلها من مكان لآخر، ت<mark>أكد من تجنب تلف أنابيب سائل</mark> التبريد أو زيادة خطر حدوث تسرب.

18. بوجد سائل التبريد إيزوبوتان (R600a) – أحد الغازات الطبيعية الصديقة للبيئة وال<mark>سريعة الاشتعال – داخل دائرة</mark> تبريد الجهاز. يُرجى التأكد من عدم تلف أي من أجزاء دائرة التبريد عند نقل الثلاجة وتركيب<mark>ها. يعد سائل التبريد (R600a</mark>) سريع

19. تحذير: لا تعرِّض فتحات التهوية الموجودة داخل الثلاجة أو الهيكل الخارجي لأ<mark>ي انسداد.</mark>

20. تحذير: احرص على عدم التسبب بأي تلف في دائرة التبريد.

21. تحذير: لا تستخدم الأدوات الكهربائيّة داخل حُجرات تخزين الطعام في الث<mark>لاحة إلا إذا كانت من الأنواع ا</mark>لتي توصي بها حهة التصنيع.